



2602.2 GoPro Mount Kit for DSLR Top Mount

Assembly Instructions

See Diagram A - reverse side

1. Place the Shoulder Washer on the Screw with the beveled edge against the Screw Head.
2. Drop the 1/4-20 x 7/8" screw with Shoulder Washer into the top of the Flex Mount.
3. Using a flathead screwdriver, attach the Flex Mount to the Top Mount of an Ikelite DSLR housing.
4. Apply a thin film of lubricant to attachment points as shown in Diagram A.
5. Press each component together.

**Ikelite Underwater Systems
50 West 33rd Street
Indianapolis, IN 46208 USA**

www.ikelite.com

© 2013 Ikelite Underwater Systems

Diagram A

