

## Instruction Manual for Battery Pack for NA-A6500 Housing

PN# 36331

### FOREWORD

Thank you for your purchase of a NAUTICAM product.

At NAUTICAM, we pride ourselves in the ability to recognize the requirements of professional as well as amateur underwater photographers and fulfill them through the innovative designs of our products. We strive to achieve a high level of user-friendliness by allowing stress-free installation and easy operation of all important functions of the camera.

Please read this manual carefully before using the product, this will maximize its performance as well as its lifetime.

### WARRANTY

All NAUTICAM Products are warranted against any material and manufacturing defects for two years from the date of purchase for consumer use. This warranty only applies to products purchased from authorized NAUTICAM dealers and does not extend beyond the original retail purchaser.

To return your product for service, please contact your regional authorized service center(s). Please note that this warranty only applies when the product is purchased in the territory where the service center is located.

NAUTICAM does not hold responsibility for damage, of any nature, to any equipment used with and/or placed within our products.

NAUTICAM accepts no liability for any loss of captured images or the inability to capture images even if it is due to the malfunctioning of our products.

Unauthorized modifications and/or repairs of our products will automatically invalidate the warranty.

### PRECAUTIONS

- Do not store the product in an environment of high humidity.
- Do not leave the product in direct sunlight for prolonged periods.
- Keep out of reach of children, failure to do so could result in injury.
- Defective products should be shipped to our distributors for service, unauthorized disassembling and/or modifications could result in malfunction.


### PACKAGE CONTENTS

- 2500mAh Battery Pack
- Micro USB cable


### SPECIFICATIONS

Dimensions:	92mm x 58mm x 6.5mm
Weight:	Approx. 70g
Capacity:	2500mAh
Input:	DC 5V / 1A
Output:	DC 5V / 1.5A
Type:	Polymer Lithium-Ion Battery
Life Cycle:	Recharge 500 times
Recharge time:	Approx. 2.5hrs

### IDENTIFICATION OF PARTS




### INSTALL THE BATTERY PACK INTO THE HOUSING



Connect the micro USB cable to the battery pack and slide into the slot at the bottom of the housing as shown.



Plug the micro USB cable into the camera's micro USB port.



Confirm that the battery pack is active and charging the camera before closing the housing. The battery level icon in the camera will change to a socket icon when external battery is connected.

### Tips:

It is suggested to always check if the battery pack is active before going into water. The battery pack will be inactive once the camera battery is fully charged. Re-plug in the micro USB cable is required to re-activate the battery pack.